



Ply Lag

Description:

OCM, Inc's Ply Lags are used to fasten wales or strongbacks. They can also be used internally to fix coil ties (etc.) to the form.

Features:

- Made with high strength steel.
- Available in 9 different lengths.

Additional Notes: SWL provides a safety factor of approximately 2 to 1.

| Item Number | Safe Working Load (lbs) | D Size (in) | L Length (in) | Overall Length (in) |
|-------------|-------------------------|-------------|---------------|---------------------|
| PL50-14.75 | 3,000 | 1/2" | 11" | 14-3/4" |
| PL50-5.75 | 3,000 | 1/2" | 3" | 5-3/4" |
| PL50-6.25 | 3,000 | 1/2" | 3-1/2" | 6-1/4" |
| PL50-6.75 | 3,000 | 1/2" | 4" | 6-3/4" |
| PL50-7.25 | 3,000 | 1/2" | 4-1/2" | 7-1/4" |
| PL50-8.75 | 3,000 | 1/2" | 6" | 8-3/4" |
| PL50-9.75 | 3,000 | 1/2" | 7" | 9-3/4" |
| PL50-10.75 | 3,000 | 1/2" | 8" | 10-3/4" |
| PL50-12.75 | 3,000 | 1/2" | 10" | 12-3/4" |