



## OCM-FLB

### Installation:

1. Attach the form liner clamp to the waler. Use duplex nails.
2. Install the 2X4 Strongback through the open back of the liner clamp with the wedge hanging down and loose.
3. Rotate the wedge up and tighten with a hammer.

<b>Part Number</b>	OCM-FLB
<b>Weight Per Piece (lbs)</b>	1.3
<b>Finish</b>	Galvanized
<b>Bucket Quantity</b>	25