



OCM-JCL

Installation:

1. Set one waler flush at the corner and let the other extend past the flush one. Slide the Corner Lock into place with the handle perpendicular to the waler.
2. Nail the Corner Lock in place and rotate the handle toward the waler until a secure tight fit is achieved.

Part Number	OCM-JCL
Weight Per Piece (lbs)	1.78