



## PL50-9.75

OCM, Inc's Ply Lags are used to fasten wales or strongbacks. They can also be used internally to fix coil ties (etc.) to the form.

<b>Part Number</b>	PL50-9.75
<b>Safe Working Load (lbs)</b>	3,000
<b>D Size (in)</b>	1/2"
<b>L Length (in)</b>	7"
<b>Overall Length (in)</b>	9-3/4"