


Spreader Cleats



To Order
(Call, Fax or e-mail this form)

1. Part No. : _____

2. Quantity : _____

3. Wall Thickness : _____

4. Plywood : _____

Phone : 1-866-457-5710

Fax : 1-847-541-9338

e-mail : sales@ocm-inc.com

OCM Part No.	End Size	Wall Thickness	Weight per pcs	Qty per Box	Safe Working Load lbs
SC06-75	3/4"	6"	0.36	100	750
SC08-75		8"	0.43		
SC10-75		10"	0.48		
SC12-75		12"	0.53		
SC0562-118	1 1/8"	5-5/8"	0.34		
SC06-118		6"	0.41		
SC0762-118		7-5/8"	0.45		
SC08-118		8"	0.47		
SC09-118		9"	0.50		
SC10-118		10"	0.52		
SC1162-118		11-5/8"	0.55		
SC12-118		12"	0.57		

SWL provides a safety factor of approximately 2 to 1.